



**NOTES:**

1. Fill sand bags about 2/3 full before placing in the gutter.
2. Place two or more sets of sand bags in a manner that results in maximum support. The flow line bag must be lower than the top of the curb.

STREET GRADE (%)	SPACING BETWEEN BAGS (FT)
0.5	100
1.0	50
2.0	25
3.0	16
4.0	13
5.0	10

CITY OF ARROYO GRANDE - ENGINEERING DEPARTMENT

STANDARD PLAN

ISSUE DATE:

**CURB AND GUTTER  
SEDIMENT CONTAINMENT SYSTEM**

**656-AG**

OCT 14, 2003

Don Spagnolo, P.E.  
Director of Public Works/City Engineer  
L.C.E. No. 42993

Sheet 1 of 1